

# RAZOR® EX Pouch Loading Protocol-at-a-Glance

**1**

## GATHER SAMPLE



OR





OR

**2**




## TRANSFER SAMPLE TO UNKNOWN BUFFER AND MIX SAMPLE

**3**


## LOAD 2mL OF MIXED SAMPLE INTO SAMPLE INJECTION PORT (ORANGE LABEL)

**4**




## LOAD 2mL OF CONTROL BUFFER INTO CONTROL INJECTION PORT (BLACK LABEL)

**5**



## REMOVE COMB AND TWIST PLUNGERS

**6**

## PLUNGE USING INSTRUMENT SURFACE BRACKET ON RAZOR EX

**7**

## INSERT POUCH INTO RAZOR EX AND RUN SAMPLE



INSERT POUCH INTO RAZOR EX

START ANALYSIS

READ RESULTS